



### **Hayabusa Ram Air Ducts**

Remove the airbox and carefully grind off both sides of the foam and the raised lip on the end of the air inlets on the airbox.

Once that is done make sure the sleeves slide over smoothly.

Apply Permatex Silicone to the beginning and the outside (not the inside where the airflows) and slide the sleeves into the air inlet tubes. Reapply the airbox and tighten it down. Once that is done slide the sleeves towards the frame until it touches the frame and align them so that they are flush.

Let the Permatex dry as directed. Once the Permatex has dried roll the rubber seals so that the gap is covered, use a screwdriver to roll the bottom on the rubber seals.